## **FLEX® SYSTEM** For installation on top of any flooring surface

IIIIII



SPEC GUIDE

Updated 08,23,2023

## **HOW WE CAN HELP**

### **Online Videos**

See how the Flex<sup>®</sup> Raceway System is built out and configured with other innovative Legrand products.

View our online video repository.

connectrac.com/home/videos



### Design Team Services

Connectrac<sup>®</sup> believes in providing exceptional customer service by offering unique resources like our Design Team.


These industry specialists are available to help you specify the best Flex solution for your next project.

### connectrac.com/design-services



### General Info & Questions

Contact us any time! | 🐛 877.480.5637 | 🖂 info@connectrac.com



## **TABLE OF CONTENTS**

What is Flex <sup>®</sup> ?	Pg 4
How it Works	Pg 6
Get Started	Pg 8
Flex Data Capacity	Pg 9

## **FLEX SYSTEM** For installation on top of any flooring surface

A floor-based power and data distribution system that allows users to quickly add connectivity or change power locations in a snap. Any Space. Any Building. Any Time.®

\*Silver finish shown here

4

### **Connectrac Flex**° is...

# Available in these finishes:



Silver (SV)





### Start Anywhere

Start a Flex run anywhere in your space - from the wall or from an open area with a 4" core hole. \*Poke-Thru and Surface-Mounted Entrance Fittings also available. Start a Flex run anywhere in your space - from the wall or from an open area with a 4" core hole.

### Interchangeable Power Devices

С

Quickly snap into any Power Hub location

Entrance Fitting Quick connector powers entire raceway & allows

data to enter

Α

B Raceway

Powertrac Pre-wired raceway segment

### **Power Hub**

- 27 Frie

Connects Powertracs & provides access for power devices

## **HOW IT WORKS**


Explore the graphic to learn more about the Flex system for installation on top of any flooring surface. Top Cover & Transition Ramps

### Data Device

С

00

Snaps into the raceway to provide data connectivity



TIP: For greater flexibility at minimal cost, add more Power Hubs and connect shorter Powertracs.

# Where is power being supplied from?

Wall or Poke-Thru

# *How much data do you need?*

## 0-6 cables

Typical for conference rooms

**Turn to Next Page** 

## 7-24 cables

Typical for up to 12 workstations


Turn to Page 16



## 25-42 cables

Typical for up to 21 workstations

Turn to Page 22



**Entrance Fitting** Choose where your Flex raceway will draw power from: Wall or Open Floor Space













Poke-Thru

Use when cabling is running INSIDE the wall.



Base Trim included

Transition accessories

included



Use when cabling is running OUTSIDE the wall, THROUGH a 2400 or 4000 series raceway:

Raceway Entrance Fitting with 3' pre-wired conduit, 4 circuit



4. Poke-Thru Entrance Fitting Use when cabling is in the CENTER of a space:

4" Poke-Thru Transition and compatible On-Floor Poke-Thru Entrance Fitting. Available for Powertracs and Datatracs in both Silver and Dark Gray finishes.




 $\bigcirc$ 0 Data Cables

Wall Entrance Fitting





**Raceway** Continue to build your raceways by connecting Powertracs and Power Hubs.




\*Powertrac measurements are based on the on-center distance between the Entrance Fitting and/or Power Hubs.

**Devices** Equip your Flex raceway system with power & data devices.



Equip your Flex raceway system with power & data devices.

**V** Data Devices These devices go anywhere on the raceway.



DESCRIPTION


Allows cables to enter/exit raceway

Fits up to 8 low-voltage keystone modules

V Data Device







Cables

Data

9

 $\bigcirc$ 

× Ш

## **Optional Accessories** Enhance your raceways with these additional options.

### Accessories

DESCRIPTION

Vertical Wire Manager Attaches to any power or data device to manage cabling

**Rough-In Frame** Installed before drywall to provide a rough opening for cabling

### Extra Hubcap

Creates a walkable surface and makes power easily accessible for future needs











## Complete Raceway

Shown with Top Covers, Transition Ramps, and End Ramps installed.

\*Silver finish shown here





























**Raceway** Continue to build your raceways by connecting Powertracs and Power Hubs.



\*Powertrac measurements are based on the on-center distance between the Entrance Fitting and/or Power Hubs.

Cables

Data

-24


ЖШ

**Devices** Equip your Flex raceway system with power & data devices.



**Devices** Equip your Flex raceway system with power & data devices.

**V** Data Devices These devices go anywhere on the raceway.








WALL

V Data Device



## **Optional Accessories** Enhance your raceways with these additional options.

### Accessories

DESCRIPTION

Vertical Wire Manager Attaches to any power or data device to manage cabling


**Rough-In Frame** Installed before drywall to provide a rough opening for cabling

### Extra Hubcap

Creates a walkable surface and makes power easily accessible for future needs











## Complete Raceway

Shown with Top Covers, Transition Ramps, and End Ramps installed.



\*Silver finish shown here





























**Raceway** Continue to build your raceways by connecting Powertracs and Power Hubs.




\*Powertrac measurements are based on the on-center distance between the Entrance Fitting and/or Power Hubs.

## **Devices** Equip your Flex raceway system with power & data devices.



**Devices** Equip your Flex raceway system with power & data devices.

**V** Data Devices These devices go anywhere on the raceway.




DESCRIPTION

Grommet Allows cables to enter/exit raceway

Data Device Fits up to 8 low-voltage keystone modules

V Data Devices





Cables

Data

42

25-

FLEX

## **Optional Accessories** Enhance your raceways with these additional options.

### Accessories

DESCRIPTION

Vertical Wire Manager Attaches to any power or data device to manage cabling


**Rough-In Frame** Installed before drywall to provide a rough opening for cabling

### Extra Hubcap

Creates a walkable surface and makes power easily accessible for future needs









## Complete Raceway

Shown with Top Covers, Transition Ramps, and End Ramps installed.

FLEX

25



8707 Chancellor Row Dallas, Texas 75247 1.877.480.5637 connectrac.com

FOLLOW US



© 2023 Legrand All Rights Reserved CS3210 08/23